

# Handle

	Fitting group
STRAIGHT H-190 Wood SB No.07995	A
STRAIGHT H-270 Wood LB No.07990	B
STRAIGHT H-270 Wood No.15994	C
STRAIGHT H-300 Wood No.15990	D
STRAIGHT H-300 Red No.15952	D
STRAIGHT H-300 Blue No.15953	D
STRAIGHT H-300 Black No.15971	D
STRAIGHT H-150 No.15958	D
STRAIGHT H-240 Wood LH No.08990	E
STRAIGHT H-240 Wood SH No.08992	E
PISTOL H-126 Yellow No.08993	E
PISTOL H-126 Blue No.08996	E

	Fitting group
PISTOL H-126 Red No.08991	E
PISTOL H-126 SH No.15278	E
STRAIGHT H-330 Wood No.15991	F
STRAIGHT H-330 Orange No.15973	F

# Combination

⊙ recommended ○ possible

Fitting group		A	B	C	D, E	D, E	F
Fitting group	Handle						
	Blade						
A	DOZUKI FINE150 DOZUKI HARDWOOD150 DOZUKI PIERCING 150 DOZUKI BAMBOO H-150	⊙					
B	DOZUKI FINE 240 DOZUKI HARDWOOD 240		⊙				
C	CROSS H-225			⊙	○	○	
D	CROSS H-250 RIP H-250 UNIVERSAL H-250 HARDWOOD H-250 CROSS H-265 UNIVERSAL H-265 CROSS CONVEX H-265 RIP H-300 BAMBOO H-270			○	⊙	⊙	○
E	PVC 240 SIDING H-120 COPPER 240 UTILITY H-240 TAPERED UTILITY FLUSH H-240 IRON 240 PVC 300			○	⊙	⊙	○
F	UNIVERSAL H-300 CROSS CONVEX H-300 HEAVY DUTY H-333				○	○	⊙

Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with a rag when replacing the blade.

