Blade replacement

Detachment

Loosen the screw with a coin or a screwdriver and pull the blade out from the handle.


Attachment

31

Insert the blade and tighten the screw to fix the blade firmly.

FS-245 P3.5









Universal Sheath: Suitable for left or

right handed people





Sawing rhythmically and adding force while pulling can greatly enhance sawing efficiency.



The firm blade and extremely sharp teeth make this saw ideal for fruit tree pruning and general gardening.



NO.	ITEM	BOX	CTN	SPEC	
52431	Saw	6	36	Blade Length	240mm
52432	Blade	24	_	Pitch Thickness	3.50mm 0.90mm



This 270mm length blade featuring extremely aggressive sharp teeth makes this saw ideal for forest tree trimming and gardening.





NO.	ITEM	BOX	CTN	SPEC	
52433	Saw	6	36	Blade Length	270mm 3.50mm 0.90mm
52434	Blade	24	_	Pitch Thickness	

FS-210 P3.0

Ideal for pruning apple, olive, plum and other fruit trees.



NO.	ITEM	BOX	CTN	SPEC	
52421	Saw	6	36	Blade Length Pitch Thickness	210mm 3.00mm 0.70mm
52422	Blade	24	288		

FS-240 P2.4

Ideal for pruning apple, pear and other fruit trees.





Ideal for pruning apple, peach and other fruit trees.



52424





288



Blade Length

Thickness








240mm

2.40mm

0.70mm



32